

o. user programs

The user programs allow the parameters of certain functions to be set, changed, or canceled as desired.

(1) List of user programs

Program No.	Program name	Description
1	Auto clear time	Sets the auto clear time. The copier returns to the initial settings when the auto clear time elapses after the last copy is made.
2	Preheat mode	Sets the time that elapses before the copier enters the preheat mode after any operation made.
3	Auto power shut-off mode	Sets the time that elapses before the copier enters the auto power shut-off mode after an operation is made.
4	Auto power save control	Enables or disables the automatic power save control function.
5	Stream feeding mode*	Enables the stream feeding mode when an optional automatic document feeder is installed.
7	Sorter bin up/down mode*	Enables or disables the sorter bin up/down mode when an optional sorter is installed.
8	Auto paper select mode	Enables or disables the auto paper select function.

\* These programs do not affect the copier functions unless certain optional equipment is installed.