

Service
Service
Service



Philips Consumer Lifestyle

Service Manual

PRODUCT INFORMATION

- This product meets the requirements regarding interference suppression on radio and TV.
- After the product has been repaired, it should function properly and has to meet the safety requirements as officially laid down at this moment.

TECHNICAL INFORMATION

- Voltage : 220 - 240 V
: 110 V
- Frequency : 50 - 60 Hz
- Power consumption (220 - 240 V) : 950 W
(110 V) : 800 W
- Coloursetting HD2566/00 : White
HD2566/20 : Black / Grey
HD2566/40 : White / Red
HD2566/70 : White / Blue
- SAP coding : HD2566

REPAIR INSTRUCTIONS

- In case of a technical defect, toaster has to be replaced.
Only crumb tray and lid are available as spare part.


ASSEMBLY & DISASSEMBLY ADVICE

- No specific issues

OPTIONAL (accessories)

- No specific issues

■ = changed



Pos	Service code	Description	
1	996500034075	Lid	Translucent blue
	996500034074	Lid	Translucent white
2	996500034076	Crumbtray	White
	996500034077	Crumbtray	Grey
	996500034078	Crumbtray	Red
	996500034079	Crumbtray	Blue