







(2) Setting the user programs

Procedures	State	Alarm indicators of paper jam, maintenance, paper supply, toner supply	Entered value display	Print button LED
1. Press and hold the TRAY SELECT key for more than 5 seconds until all the alarm indicators blink and "-." appears in the copy quantity display.	User program mode	Blink		OFF
2. Enter a program number using the 10-key pad.	Program code selection	Blink	 Example	ON
3. Press the print button.	Program code determination	Blink		ON
4. Select the desired parameter using the 10-key pad.	Parameter selection	Blink		ON
5. Press the print button.	Parameter determination	Blink	1 2	OFF
6. Press the TRAY SELECT key.	Exit from user program.	OFF	Returns to the copy quantity display.	-
* Press the clear key.	(Use this key to correct an error in input.) • When this key is pressed after completion of program setting, the input for the next program is allowed.	Blink		OFF

(  Blink)

(3) List of parameters

Program	Code	Parameter	Factory setting
Auto clear time	[1] [2] [3] [4]	[0]: OFF [1]: 30 sec [2]: 60 sec [3]: 90 sec [4]: 120 sec	2
Preheat mode	[2]	[0]: OFF [1]: 30 sec [2]: 60 sec [3]: 90 sec [4]: 120 sec	0
Auto power shut-off mode	[3]	[0]: OFF [1]: 2 min [2]: 3 min [3]: 5 min [4]: 10 min [5]: 15 min	0
Auto power save mode	[4]	[0]: OFF [1]: ON	1
Stream feeding mode	[5]	[0]: OFF [1]: ON	0
Sorter bin up/down mode	[7]	[0]: OFF [1]: ON	1
Auto paper select	[8]	[0]: OFF [1]: ON	1