

Service Service Service



Service Manual

Contents

Chapter

- 1 Disassembly
- 2 Mechanism adjustments
- 3 Electrical adjustments
- 4 Charts and diagrams
- 5 Parts lists
- 6 Technical information

Specification:

Video recording system:	Rotary four head helical scan system
Video Signal:	PAL B/G, D/K
Antenna:	VHF/UHF – 75Ω external antenna terminal
VHF Output Signal:	UHF Channel 36 (32-40), 75Ω unbalanced
Power requirement:	AC110-240V, 50/60Hz
Power consumption:	18W
Operating temperature:	41°F (5°C) to 104°F (40°C)
Relative humidity:	10% to 80%
Weight:	3.8kg
Dimensions:	360 x 94 x 307mm

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified be used.

RTV servis Horvat

Kešinci, 31402 Semeljci

Tel : 031-856-637

Tel / fax : 031-856-139

Mob : 098-788-319

rtv-servis-horvat@os.tel.hr



PHILIPS

1. CABINET AND CHASSIS ASSEMBLY <M2>



