



SERVICE INFORMATION

1. RESISTANCE VALUES ARE INDICATED IN OHMS UNLESS OTHERWISE SPECIFIED. (K=1,000, M=1,000,000)
2. CAPACITANCE VALUES ARE SHOWN IN MICROFARADS UNLESS OTHERWISE NOTED. (P=PICTO-MICROFARADS)
3. DC : NO SIGNAL EXCEPT WHERE INDICATED.
4. AC : RMS UNLESS OTHERWISE SPECIFIED.
5. ALL COMPONENTS MARKED MUST BE REPLACED ONLY WITH ORIGINAL TYPE SPECIFIED BY THE MANUFACTURER. INTER M CORPORATION AND INSTALLED AS THE ORIGINAL SPACE SAVING EQUIPMENT. INTER M CORPORATION AND INSTALLED AS THE ORIGINAL SPACE SAVING EQUIPMENT. INTER M CORPORATION AND INSTALLED AS THE ORIGINAL SPACE SAVING EQUIPMENT.