

Connector colours

Nr	Black	Or	Orange
Be	Blue	Rg	Red
Mr	Brown	Ba	White
Gr	Grey	Jn	Yellow
Ve	Green		

Key to items

1	Battery
2	Ignition switch
3	Engine fuse box
4	Passenger fuse box
76	Heater blower panel
77	Heater blower switches
78	Heater blower resistor pack

79	A/C heating controls
80	Blower motor
81	A/C panel
82	Passenger compartment thermostat
83	Evaporator temperature sensor


84	A/C switches
85	Blower motor relay
86	A/C compressor relay
87	A/C compressor
88	A/C cut-off relay
89	Pressostat
90	A/C control unit

91	Engine coolant temperature sensor
92	Engine cooling relay
93	Cooling fan switch
94	RH cooling fan
95	LH cooling fan


Diagram 6

MTS H39272

Heater blower



Typical engine cooling



Air conditioning

