

<b>THOMSON</b>	<b>TELEFUNKEN</b>	<b>SABA</b>	<b>NORDMENDE</b>
<b>ICC 4</b>	<b>417</b>	<b>SC 90</b>	<b>F 14</b>
<b>ICC 5</b>	<b>517/518/617/618AB</b>	<b>SX50/SX55/SX58</b>	<b>F15/F16/F17/F18</b>
<b>ICC 6</b>	<b>ICC 6</b>	<b>ICC 6</b>	<b>ICC 6</b>
<b>ICC 7 / ICC 8</b>	<b>418B / 418C</b>	<b>SB70/SB75/SC80/ SC85</b>	<b>F 23 / F 24</b>
<b>ICC 9</b>	<b>ICC 9</b>	<b>ICC 9</b>	<b>ICC 9</b>
<b>ICC 10 / ICC 11</b>	<b>ICC 10 / ICC 11</b>		<b>ICC 10 / ICC 11</b>
<b>ICC 17</b>	<b>ICC 17</b>	<b>ICC 17</b>	
<b>ICC 19 (50Hz)</b>	<b>ICC 19 ( 50Hz)</b>	<b>ICC 19 (50Hz)</b>	
<b>ICC 19 (100Hz)</b>	<b>ICC 19 (100Hz)</b>	<b>ICC 19 (100Hz)</b>	
<b>ICC 20</b>	<b>ICC 20</b>	<b>ICC 20</b>	
<b>IDC 2</b>	<b>619 / 619A</b>	<b>SB 220</b>	<b>DC 1 / DC 2</b>
<b>IKC 2</b>	<b>418A / 418 A1</b>	<b>SX 20 / SX 25</b>	<b>F 19 / F 20</b>
<b>TX 80</b>	<b>318A</b>	<b>SX 08</b>	<b>F 22</b>
<b>TX 805</b>	<b>TX 805</b>	<b>TX 805</b>	<b>TX 805</b>
<b>TX 807</b>	<b>TX 807</b>	<b>TX 807</b>	<b>TX 807</b>
<b>TX 90</b>	<b>318B</b>	<b>SC 09</b>	<b>F 26</b>
<b>TX 91</b>	<b>TX 91</b>	<b>TX 91</b>	<b>TX 91</b>
<b>TX 92 / TX 92F</b>	<b>TX 92 / TX 92F</b>	<b>TX 92 / TX 92F</b>	<b>TX 92 / TX 92F</b>
<b>EURO-COMBO</b>	<b>EURO-COMBO</b>	<b>EURO-COMBO</b>	