


JP208

JP208



Part of board connected to mains supply.

△ Safety Part

Note : Power Supply primary circuit measurements: - Use only (PGND) connection point.