

## 2. Washingprogrammes and options

### 2.1 Programmes

The washing programmes can be configured. The basic programmes are listed in the table below.

Programme		Temperature (°C)	Number of rinses	Final spin (rpm)
Cotton	90	85	3	450/650/850/1000/1200/ 1300/1400/1600
	90E	67	2	
	60	60	3	
	60E	50	2	
	50	50	3	
	50/40E	44	2	
	40	42	3	
	30	30		
	cold	20		
Synthetic fabrics	60	60	3	Max. 900
	60/50E	42		
	50	50		
	40	40		
	30	30		
	cold	20		
Delicates	40	40	3	450/700
	30	30		
	cold	20		
Wool	40	40	3	Max. 1000
	30	35		
	cold	20		
Hand-wash	40	40	3	Max. 1000
	30	35		
	cold	20		
<b>Soak</b>		30/20	----	----
<b>Rinses</b>		----	3	Max. 1600
<b>Delicate rinses</b>		----	3	Max. 700
<b>Conditioner</b>		----	1	Max. 1600
<b>Drain</b>		----	----	----
<b>Spin</b>		----	----	Max. 1600
<b>Delicate spin</b>		----	----	Max. 700
<b>Mini</b>		30	2	Max. 1000