

Philips		MD1.2E	CTV	Service Mode	<p>There is a small Service jumper to short on the small signal PCB. When the TV is in this first level service mode, you can go in the second level service mode by pressing both MENU and - keys on top of the TV at the same time.</p> <p>There you can read much parameters and proceed with most of the adjustments. In fact this method let you use an ordinary Remote control but you also need to open the back cover. With the special service remote control, a special code is sent to enter the service mode.</p>
---------	--	--------	-----	--------------	---