



5. Troubleshooting

5-1 No Power




Note : When you check whether any component is normal, you must let the output pin be open in order not to be affected by the side of output.

5-2 No Picture



5-3 No Sound



MEMO