


TOUCH PANEL and CONTROL BOARD



Error Codes	Corrective Action
F1	Replace Board.
F2	Replace Board.
F3	Replace Board.
F4	Replace Board.
F5	Replace Touch Panel.
F6	Replace Board.