

*Thank you for choosing Meliconi.*

This universal remote control is used for all the main functions of 2 remote controls (TV and VCR) of the brands listed at the back of the pack.

*Keep your Instructions Booklet and Code Booklet for future reference.*

**USING THE KEYS AND FUNCTIONS**

VCR selection key for using the VCR. This key lights up whenever you use a VCR command.

TV and VCR ON/OFF key.

Used to access additional commands and to program the remote control.

TV selection key for using the TV. This key lights up whenever you use a TV command.

Number keys.

To access your MENU. Move within the MENU using the **▲** +/- and **▼** +/- keys or **SHIFT** with **▲** +/- **▼** +/- depending on the model of your original remote control.

Teletext keys:

- to access Teletext
- to close Teletext and return to normal viewing
- Teletext page hold function
- additional Teletext function.

Control the volume using +/- . These keys can also be used to move to the right and left in the MENU.

Confirm key.

To select the next (**P+**) or previous (**P-**) channel or program. These keys can also be used to move up and down in the MENU.

To select an external terminal.

Mute key.

User customisation keys for memorising and accessing additional commands.

TV	VCR	TV	VCR
Fastext Func.		Fastext Func.	
-	Record	White/Violet	Additional Func.
Red	Rewind	Blue	Fast forward
Green	Stop	Yellow	Pause
		-	Play

*The functions described above are only operative if your appliance also has them.*



- GETTING START
- CODE RESEARCH
- AVAILABLE FUNCTIONS AND PROGRAMMABLE KEYS
- USE INFORMATION
- BATTERIES
- FREQUENTLY ASKED QUESTIONS
- CONTACT US

## CODE RESEARCH

BACK

There are three ways to find and enter the right code in the CONTROL 2:

- FAST RESEARCH** (suggested)  
Through the on-line program "CODE RESEARCH" you can find the programming codes. It also shows the cross reference list between the buttons of the original remote control and our CONTROL 2.
- BRAND RESEARCH** (as alternative)  
This procedure must be executed directly on the CONTROL 2. It allows you to try the complete BRAND CODE RANGE, one by one, in order to find the proper code for your appliance.
- GLOBAL RESEARCH** (as last option)  
This procedure is similar to the one described above, but it will try with **each** code entered in its memory. (you must be very patient!!!)

## CODE ENTERING

Procedure to be followed to enter the code.

## IDENTIFICATION OF THE IN USE CODE

Procedure to be followed in order to identify the in use code, found with the BRAND or the GLOBAL RESEARCH.

MELICONI - HELP ON-LINE CONTROL 2 - Google Chrome

www.cme.it/meli1/pag2.php?idm=gb&oem=mel&mtm=c2&nbu=EA020&mti=43542d32314

**AKIRA (004)**

**ATTENTION !**  
no model has been found  
for the typed reference

**CT-21CQS**

BACK

**INSTRUCTIONS**  
If the desired model is not found, repeat the search on **ALL BRANDS**.  
It may happen that an appliance is on the market with more brands.  
  
If the typed model is not identified, note the red code beside the brand name. Follow the **BRAND RESEARCH**, and carry it out directly on the **remote control MELICONI**.  
  
To look for unknown models use the **GLOBAL RESEARCH**.

Technika TT-706.pdf Technika... C...pdf

Osszes letöltés megjelenítése...