
SOUND PROCESSOR
I302
TDA9870A/75A
TUNER
TU01
AUDIO AMPLIFIER
IA01 TDA2615 (TDA2616)
RESET
EEPROM
IC02
24C16
uCONTROLLER+VIDEO PROCESSOR
TDA93X5/6X/8X
IV01
MONO/OPT.
IA50
TDA7056A
SERVICE
INFRARED MODULE
DOLBY AMPLIFIER
IA51
TDA7057AQ
SECAM L MONO SOCKET
DOLBY SOCKET
HOTELTV SOCKETS
HEADPHONE AMPLIFIER
TDA7050
IH01
VIDEO SWITCH
E/W DRIVE
VERTICAL
TDA8356
(TDA8351)
SCARTS
KE02
SCART20'21
KE01
SCART20'21
KE04
CRT BOARD
99TA001
TDA6107Q
I001
POWER SUPPLY
TDA16846
IP01
IP02
L4940V5
IP03
TDCT11010
IP04
HORIZONTAL
WD02
FBT
PT92 WEBTV CHASSIS SCH.DIAGRAM
VER.A
23/06/2001
ALL RIGHTS RESERVED